



SEMPRE-BIO



SEMPRE-BIO Project: Comparison of Three Innovative Scaled-Up and Optimised Technologies For Biomethane Production and Its Purification

Filippo Bisotti, Matteo Gilardi, Bernd Wittgens
SINTEF Industry – Process Technology





Scan the QR code Visit our webpage and subscribe the newsletter



Outlines



1

Introduction

Role of biogas in the EU decarbonization strategy

2

Processes overview

Block flow diagrams

3

Results

Main KPIs and other comments

4

Conclusions

Achievements & future works

1. Introduction




Biogas production




- Mainly produced via **anaerobic digestion**
- **CH₄** content variable from **45 to 75 vol%**
- The remaining is **wet CO₂** with **traces of NH₃ and H₂S**
- **Upgrading** is necessary for applications of bio-CH₄ as **fuel** or **transport** (either gas or liquid)

European Biogas Association - <https://www.europeanbiogas.eu/>
IEA - <https://www.iea.org/reports/outlook-for-biogas-and-biomethane-prospects-for-organic-growth/an-introduction-to-biogas-and-biomethane>




Source: VectorMine / Getty Images

Biogas production



- Upgrading is crucial to meet **specs for transport in the NG grid**
- Upgrading is also relevant for **liquefaction** and delivery (supply chain)



SEMPRE-BIO project



SEMPRE-BIO

SEcuring
doMestic
PRoduction of
cost-Effective
BIOmethane

Total funding
€ 9 926 450

HORIZON-IA



- SEMPRE-BIO aims at **demonstrating novel and cost-effective bio-CH₄ production solutions** to support the circular economy and **reduce dependence on fossil fuels**
- Biomethane production tested in **3 demo plants** across Europe accounting for **different feedstocks**

CETAQUA
WATER TECHNOLOGY CENTRE

Biogas-
platform voor anaerobe vergisting

Naturgy 

 Cryo Inox

inventam 
Supporting technology pathways


UNIVERSITEIT
GENT

 terrawatt


Aigües de
Barcelona


Lab 4 Biomass

 DBFZ

NV De
Zwanebloem


Beta
UNIVERSITAT DE VIC
UNIVERSITAT CENTRAL DE CATALUNYA

 TMB

ProPuls

DTU


 SINTEF

 BIOTHANE


Case studies



**Aigües de Barcelona,
Barcelona, Spain**



**Terrawatt,
Marmagne, France**

Bio-CH₄ synthesis/production



**De zwanebloem,
De Panne, Belgium**

Biogas upgrade and
bio-CH₄ Liquefaction

Source: SEMPRES-BIO webpage

2.Processes



CSI



Aigües de Barcelona, Barcelona, Spain


Direct biomethanation of
biogas



BFD CSI



- **Direct biomethanation of biogas** to bio-CH₄
- Application for transport engines burning bio-CH₄
- Simulation in **COFE V3.10**, license-free simulation software by AmsterChem



CNG (compressed natural gas) is delivered at **20 MPa** with a residual **CO₂ of max 3 vol%**, compatible with the internal combustion engine requirement

Technology provider:

CETAQUA
WATER TECHNOLOGY CENTRE

CS2



**Terrawatt,
Marmagne, France**

Bio-syngas biomethanation




BFD CS2




- **Biomass gasification** followed by **biomethanation** of syngas

- Simulation in **COFE V3.10**, license-free simulation software by AmsterChem



Technology provider:  **terravatt**

PFD



Modelling of pyrolysis



CET CHEMICAL ENGINEERING TRANSACTIONS

VOL. 119, 2025

Guest Editors: David Bogle, Flavio Manenti, Piero Salatino

Copyright © 2025, AIDIC Servizi S.r.l.

ISBN 979-12-81206-20-5; ISSN 2283-9216

241

A publication of
AIDIC

The Italian Association
of Chemical Engineering
Online at www.cetjournal.it

DOI: 10.3303/CET25119041


A Novel Semi-Rigorous Model for Biomass Pyrolysis and Gasification

Filippo Bisotti^{a,*}, Matteo Gilardi^a, Paolo de Carli^b, Yann Mercier^b, Bernd Wittgens^a

^a SINTEF Industry – Process Technology, Trondheim, 7465, Norway

^b TERRAWATT SAS, 149, Avenue du Maine, 75014, Paris, France

filippo.bisotti@sintef.no



Scan and read the
open-access

CS3



De zwanebloem, De Panne, Belgium

Biogas upgrade and
bio-CH₄ Liquefaction



CS3




- **Upgrading** and **liquefaction** of bio-CH₄
- Application for transport of bio-CH₄ delivery in the absence of surrounding infrastructure (e.g., farms and remote biogas sites)
- Simulation in **COFE V3.10**, license-free simulation software by AmsterChem



Technology provider:




CS3A




A

CS3B



B

CS3C



C

Refrigeration cycle optimisation



Systems & Control
Transactions

Original Research Article
Peer Reviewed Conference Proceeding
ESCAPE 36 - European Symposium on Computer Aided Process Engineering
Sheffield, UK. 21-24 June 2026



Energy recovery from process purges: steam turbine integration and operation optimisation in biogas upgrading within SEMPRE-BIO project

Filippo Bisotti^{a,*}, Matteo Gilardi^{a,*}, and Bernd Wittgens^{a,*}

^a SINTEF Industry – Process Technology – P.O. Box 4760 Torgarden, 7465, Trondheim, Norway

ESCAPE36

European Symposium on Computer Aided Process Engineering

Sheffield, UK
21 - 24 June 2026



Open access paper
coming soon!


3.Results



CS1



- The most relevant property of the compressed bio-CH₄ is its dew point (T_{dew}) at 250 bar(a).
- CS1 can deliver compressed bio-CH₄ with a purity of 98.45 vol% - corresponding to -60.5°C, in line with the European standard EN 16723-2:2017 for compressed natural gas for the use of Bio-CNG





CS₂ – gasification KPI

KPI	Value	Note
Gas yield	1.23 Nm ³ _{dry syngas} /kg _{dry solid}	In line with review work [1,2]
Syngas composition	H ₂ > 45 vol% Other data are sensitive	On a dry basis without tars and in line with experimental data [1,2,3]
Tar yield	17.7 g/kg _{dry solid}	Comparable to other work [2]

[1] Marcantonio et al., 2020, Computation, 80 (4), 86

[2] Cerone et al., 2024, International Journal of Hydrogen Energy, 95, 1215-1221

[3] Gao et al., 2023, ACS Omega, 8, 31620-31631



CS₂ – gasification KPI

KPI	Value	Note
Specify energy demand	1.02 kWh _{th} /kg _{dry} (3.66 MJ _{th} /kg _{dry})	In line with review articles using different wood feedstocks [4]
HHW	12.35 MJ/Nm ³ _{dry syngas}	In line with literature values [1-4]
LHW	10.60 MJ/Nm ³ _{dry syngas}	

[1] Marcantonio et al., 2020, Computation, 80(4), 86

[2] Cerone et al., 2024, International Journal of Hydrogen Energy, 95, 1215-1221

[3] Gao et al., 2023, ACS Omega, 8, 31620-31631

[4] Daugaard D.E., Brown, R.C. 2003, Energy & Fuels, 17, 934-939

CS2 – biomethane production



	H ₂ addition	Impurities (vol%)	CH ₄ yield (Nm ³ _{CH₄} /kg _{dry solid})	Notes
CS2A (extra H ₂)	54.9 kg _{H₂} /t _{dry solid}	CO ₂ 0.03% Other sensitive	0.32 Nm ³ _{CH₄} /kg _{dry solid}	H ₂ addition pushes CO _x conversion that generates H ₂ O that is condensed
CS2B (no extra H ₂)	-	CO ₂ 30.06% Other sensitive	0.15 Nm ³ _{CH₄} /kg _{dry solid}	



CS3 – refrigeration

	Refrigeration layout	HC mixture	NH ₃	Refrigerant use
CS3A	Single loop	800 kg/h	-	Reference
CS3B	Double loop	392.5 kg/h (mild) 326.7 kg/h (cryo) 755.2 kg/h (total)	-	-5.6%
CS3C	Double loop with two refrigerants	637 kg/h	34.0 kg/h	-16.1%




CS3 – refrigeration

	Refrigeration layout	Compression HC mixture	Compression NH ₃	Savings
CS3A	Single loop	70.8 kW	-	Benchmark
CS3B	Double loop	37.5 kW (mild) 22.6 kW (cryo) 66.1 kW (total)	-	-6.2%
CS3C	Double loop with two refrigerants	55.7 kW	5.9 kW	-13.0%



CS3 – refrigeration

	Refrigeration layout	Total electricity demand (kW) [with turbine recovery (kW)]	Compression Refrigeration (kW)	Energy from steam turbine (kW)	Energy drop on the total electricity
CS3A	Single loop	191.2 [173.0]	70.8 (37.1%)	18.2 (9.52%)	Reference
CS3B	Double loop	186.4 [168.2]	66.1 (35.5%)	18.2 (9.77%)	-2.5%
CS3C	Double loop with two refrigerants	181.9 [163.7]	61.9 (34.1%)	18.2 (10.0%)	-5.2%



Comparison

Scenario	Bio-CH ₄ production	Bio-CH ₄ purity (vol%)	Electricity demand [without electrolyser]
CS1	0.709 Nm ³ _{CH₄} /Nm ³ _{dry biogas}	98.5 vol%	11.9 kWh _{el} /Nm ³ _{CH₄} [0.30 kWh _{el} /Nm ³ _{CH₄}]
CS2	A (H ₂ added) 0.320 Nm ³ _{CH₄} /kg _{dry solid} 0.260 Nm ³ _{CH₄} /Nm ³ _{dry biosyngas}	95.2 vol%	9.1 kWh _{el} /Nm ³ _{CH₄} [Negligible]
	B (no H ₂ added) 0.150 Nm ³ _{CH₄} /kg _{dry solid} 0.122 Nm ³ _{CH₄} /Nm ³ _{dry biosyngas}	45.0 vol%	Negligible
CS3	0.093 Nm ³ _{CH₄} /kg _{dry solid} 0.591 Nm ³ _{CH₄} /Nm ³ _{dry biogas}	99.99+ vol%	Opt A: 2.21 kWh _{el} /Nm ³ _{CH₄} Opt B: 2.15 kWh _{el} /Nm ³ _{CH₄} Opt C: 2.10 kWh _{el} /Nm ³ _{CH₄}

4. Conclusions



Conclusions



- **Three different technologies** have been modelled and simulated
- The process optimisation has been performed to reduce energy demand and **identify the best operational point** of the processes (constrained to biomethane purity) to **reduce energy demand** based on the end-user application
- Analysis showed that according to the process layout, feedstock, and train of the units of operation, the energy demand can change



**Funded by the
European Union**

Disclaimer

Funded by the European Union. Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union or CINEA. Neither the European Union nor the granting authority can be held responsible for them.

Acknowledgements



This project received funding from the EU's Horizon Europe programme under grant agreement N° 101084297



Funded by
the European Union



Filippo Bisotti
Research scientist
SINTEF Industry



Matteo Gilardi
Research scientist
SINTEF Industry



Bernd Wittgens
Senior advisor
SINTEF Industry



Thank you for your kind attention!

 [SEMPRE-BIO](#)

 [@SEMPRE_BIO](#)

 [SEMPRE-BIO PROJECT](#)

 INFO@SEMPRE-BIO.COM

 WWW.SEMPRE-BIO.COM



Filippo Bisotti
filippo.bisotti@sintef.no